







Figure-7a

	Electronic Instructions
۱.	'Master Code' = Owner's code Master Code original setting is '0-0-0-0'
2.	Open Safe with Master Code START "0-0-0-0" ENTER
3.	To Change Master Code START '0 '0-0-0-0' New Master Code New Master Code
	The Master Code can be from 2 to 8 digits. The Master Code can be from 2 to 8 TART key or the * key.
	The Master Code cannot contain the START key of the When the Master Code is changed successfully the safe will beep three
4.	times. 'Back Door Code' = Safe override code Back Door Code is used to open the safe and to reset the safe Master Code
5.	to '0-0-0-0' To set the Back Door Code START ' 'Master Code' ' 'Back Door Code' '
	'Back Door Code' 'ENTER
6.	Open Safe with Back Door Code START 'Back Door Code' ENTER
7.	The Safe has a clock The clock is on for ten seconds. The Safe clock will show date and time
8.	_ all Time
	START ENTER
9	START 'MASTER CODE' * 11 'ENTER
	"Press the proper key to show the hour"
	"Press the proper key to show the minutes"

'1' for AM or '2' for PM ENTER

Figure-7b

10.	Setting the Date
	START 'MASTER CODE' 2 ENTER
	'Press four keys to sow the Month and Day' ENTER
1.1	For example, October 5 th would be '1005' or July 7 th would be '0707' Unauthorized Alarm
•••	This sets an audible alarm for approximately 30 seconds after 25 invalid keystrokes. The audible alarm will stop before 30 seconds if the correct code is entered.
12.	Notifying the owner Unauthorized Alarm was set off.
	START 'MASTER CODE' ENTER Three beeps will sound off.
	Three beeps notify the user that the safe alarm was set off.
13.	Safe History The safe history is to show the user the last twenty openings or combination of openings and unauthorized attempts.
14.	Using the Safe History START 'MASTER CODE' 3 ENTER
	The safe will show the user the last opening the code that was used and the date and time of the opening. For five seconds then the previous opening will appear. If the alarm was set off then the safe will read 'Alarm' with date and time.
	To stop the history report, press ENTER
15.	Additional codes can be entered. Additional codes can be used to open the safe without privileges the Master Cod gets. This is ideal for roommates.
16.	Additional Codes
	START 'MASTER CODE' 4 Enter New Code New Code ENTER The safe can take up to 3 additional codes.
17.	
	START 'MASTER CODE' 6 5 ENTER 'ADDITIONAL CODE' ENTER